



1 gietijzeren fondueset
15140024 - 2 L

2 mortier + stamper
15140004

gietijzeren kookpot
geschikt voor inductie
3 15141264 - Ø 26 cm - 5 L
4 15141314 - 31 cm - 5,5 L





Cosy moments - Tallina

schaaltje
1 9118112
Ø 11,5 x H 5 cm - 34 cl

biertglas ribbeke
2 1358 - 33 cl - set 6

flesopener
3 CTC600603



(cas)
Chef Sommer
KITCHEN

Cosy
& Trendy
cook - dine - live

Cosy
& Trendy
cook - dine - live



aperoset
8 8021051 - 9-dlg

aperoset
9 2123185 - 30 x H 4 cm



Cosy
& Trendy
cook - dine - live

biertglas
4 N8277 - 55 cl - set 6
5 N8280 - 35 cl - set 6
6 N8278 - 47 cl - set 6

serveerplankje
7 2709762 - 30 x 15 cm



vanaf
5,50
ST

Cosy
& Trendy
cook - dine - live

apersoset
16 7322214 - 8-dlg

Cosy
& Trendy
cook - dine - live



18,90
SET

aperschaaltje
19 Ø 7 x H 2,2 cm
3745007 ■
3445007 □
3245007 ■

serveerplank
20 2709760 - 70 x 15 cm

aperschaaltje
21 Ø 9 x H 3,8 cm - 10 cl
3745009 ■
3445009 □
3245009 ■

aperschaaltje
22 Ø 11 x H 5 cm - 30 cl
3745011 ■
3445011 □
3245011 ■

aperopannetje
10 7934278 - Ø 12 x H 4 cm
11 6111060 - Ø 12 x H 6 cm
12 5009648 - Ø 12 x H 3 cm
13 1188423 - Ø 16 x H 4,5 cm

BOSKA
14,95
SET



cheese baker incl. houder
14 340033 - 400 ml

partyclette
15 852040 - 18,5 x 8,5 x H 4,5 cm

Cosy
& Trendy
cook - dine - live



10,95

dienblad
17 8637810 - 32 x 15 x H 4 cm

etagère
18 8797347 - Ø 20,5 x H 26 cm

Cosy
& Trendy
cook - dine - live



1,50
ST

1,95
ST

20

21

22

2,70
ST

16,95



38,95

schort leder
1 1708598 - 80 x 54 cm



Leather

Madison

vanaf
4,95
ST

Cosy
& Trendy
cook · dine · live

ovenshotel met deksel
2 4364112 - Ø 12 x H 9 cm
3 4364011 - Ø 10,5 x H 7,5 cm

Richardson
Sheffield

Scandi



94,95
SET

7

messenblok
7 8448745 - 5-dlg

Madison

vanaf
2,75
ST

Richardson
Sheffield

Scandi



ovenshotel
4 4364018 - Ø 17,5 x H 4,2 cm
5 4364015 - Ø 14,5 x H 4,3 cm
6 4364012 - Ø 12 x H 4,2 cm

Scandi





Galassia

- | | |
|---|---|
| 1 diep bord
7611019 - Ø 19 x H 6,5 cm | 4 onderzetbord
AW22431030 - Ø 33 cm |
| 2 bord
7611022 - Ø 21,5 cm | 5 vaas
AW22243134 - Ø 8 x H 23 cm |
| 3 7611029 - Ø 29 cm | 6 AW22243234 - Ø 9,5 x H 29,7 cm |



Galassia

- 7** kandelaar
9790941 - H 78 cm
2908011 - H 38 cm
- 8** champagneglas
Q0818 - 35 cl - **set 6**
Q1151 - 30 cl - **set 6**



- 9** onderzetbord rvs
654178 - Ø 33 cm

Cosy
&Trendy
cook · dine · live




- 13** bord
2233447 - Ø 45 cm
- 14** houder voor zeevruchtenschaal
1065853 - Ø 19 x H 18,5 cm
- 15** oesterset
D402T1026 - 9-dlg



- 10** kreeftset
9460966 - voor 6 personen
- 11** kreeftslab
8639541 - 44 x 73 cm
- 12** bord
2233446 - Ø 35 cm






- bord
- 1 32 x 15 cm - 2923032 ■ - 5487032 ■
 - 2 34,5 x 24 cm - 2923035 ■ - 5487035 ■
- placemat leder*
- 3 6721824 - 43,5 x 28,5 cm
- kom
- 4 Ø 9 x H 4,5 cm - 15 cl - 2923109 ■ - 5487109 ■
 - 5 Ø 16 x H 5,6 cm - 72 cl - 2923116 ■ - 5487116 ■
 - 6 Ø 22,5 x H 11 cm - 2,94 L - 2923023 ■ - 5487023 ■
 - 7 Ø 13,5 x H 7,4 cm - 70 cl - 2923014 ■ - 5487014 ■



- placemat leder*
- 8 6745180 - 43,5 x 28,5 cm
- bord
- 9 25,5 x 25,5 cm - 2923126 ■ - 5487126 ■
- * recycled



- bord
- 10 Ø 20,5 cm - 2923021 ■ - 5487021 ■
- beker
- 11 Ø 6 x 7,7 cm - 16 cl - 2923006 ■ - 5487006 ■
 - Ø 8,4 x 10 cm - 35 cl - 2923010 ■ - 5487010 ■
- schoteltje
- 12 Ø 12 cm - 2923012 ■ - 5487012 ■

6



- bestekblack
- 13 5905355 - 24-dlg voor 6 pers

- bestek champagne
- 14 4514262 - 24-dlg voor 6 pers



- Amefa
- 14 55,95 SET

14

Vintage

Vintage





- | | | | |
|---|-----------------------------|-----------------------------|-------------------------|
| 1 | bord | 5 | schaal |
| 2 | 9118012 - Ø 12 cm | 9118019 - Ø 18,5 x H 6,7 cm | |
| 3 | diep bord | 6 | aperobord |
| 4 | 9118116 - Ø 16,3 x H 4,2 cm | 9118127 - 27 x 6,5 cm | |
| | | 7 | schaal |
| | | 8 | 9118113 - 11,3 x 9,3 cm |
| | | | aperobord |
| | | | 9118114 - 14 x 7 cm |



- | | |
|---------|------------------------|
| 12 | set steakmes+vork |
| 218149 | - 2 messen + 2 vorken |
| 13 | grillpan set |
| 9034895 | - 38,5 x 25 cm - 4-dlg |



- | | | | |
|---------|--------------------------|---------|-------------|
| 9 | kopje | 11 | dessertbord |
| 9118009 | - Ø 8,5 x H 6 cm - 18 cl | 9118021 | - Ø 21 cm |
| 10 | schoteltje | | |
| 9118015 | - Ø 14,4 cm | | |



- | | |
|---------|---------------------------|
| 14 | frietmandje |
| 8977030 | - 21-14 x 10 x 8,5-14 cm |
| 15 | 7781909 |
| | - 19-10,5 x 9 x 6-13,5 cm |
| 16 | leisteen bord |
| L303004 | - 30 x 30 cm |



- 1 pastamachine
9589119 - spaghetti - lasagne - fettuccine
- 2 serverplank
2709765 - 35 x 25 x H 5 cm
- 3 pasta set
9002B - 11-dlg



- 4 schaal
7011017 - Ø 16,5 x 5,3 cm
7011010 - Ø 10 x 3 cm
6 7011022 - Ø 22 x 4,3 cm
7 6011017 - Ø 16,5 x 5,3 cm
8 6011010 - Ø 10 x 3 cm
9 6011022 - Ø 22 x 4,3 cm



- 10 raclette
851500 - 220V - Ø 40 cm



- 11 serverplank
2709767 - 45 x 30 x H 2,5 cm
12 2709761 - 65 x 15 x H 1,5 cm
2709763 - 50 x 15 x H 1,5 cm
2709764 - 60 x 20 x H 2 cm
2709769 - 35 x 19 x H 1,5 cm

Cosy
&Trendy
cook · dine · live

- 13 kaasmes
320109 - 31,5 x 6,5 x 7 cm
- 14 serverplank essenhout
365665 - 62 x 20 x H 2 cm
- 15 boomschijf
734201 - Ø 28 x H 3,5 cm
- 16 kaasschaaf
357600 - 29 x 8 cm
voor halfharde en harde kazen



15,95

4,95

6,95

28,95

Cosy
&Trendy
cook · dine · live

BOSKA

vanaf
23,95
ST



Maestro

- 1** kookpot met deksel
geschikt voor inductie
15021164 - Ø 16 x H 12,5 cm - 2 L
15021204 - Ø 20 x H 15 cm - 3,7 L
15021244 - Ø 24 x H 15 cm - 5,1 L
- 2** pan
geschikt voor inductie
15027204 - Ø 20 x H 7,5 cm
15027244 - Ø 24 x H 7,5 cm
15027284 - Ø 28 x H 8 cm
- 3** pan
geschikt voor inductie
15027214 - Ø 20 x H 7,5 cm
15027254 - Ø 24 x H 7,5 cm
15027294 - Ø 28 x H 8 cm
- 4** sauteuse met deksel
geschikt voor inductie
15024244 - Ø 24 x H 10 cm - 3,1 L



39,95

vanaf
27,95
ST

9,95

- 9** marmite
geschikt voor inductie
15022244 - Ø 24 x H 20 cm - 7,4 L
- 10** saupan
geschikt voor inductie
15026164 - Ø 16 x H 10,5 cm - 1,6 L
15026184 - Ø 18 x H 11,5 cm - 2,3 L
15026204 - Ø 20 x H 12,5 cm - 3,1 L

Cosy
& Trendy
cook · dine · live

11

vanaf
12,95
ST

- 11** inductieadapter
7768894 - Ø 20 cm
2939610 - Ø 24 cm

- 12** braadslede
776545 - 37,5 x 27,5 x H 6,5 cm
13 149958 - 27 x 20 x H 5,5 cm



vanaf
26,95
ST



15,95

12

24,95

Cosy
& Trendy
cook · dine · live

- 14** saupan
geschikt voor inductie
8223872 - Ø 16 cm
7911729 - Ø 18 cm
8489497 - Ø 20 cm
- 15** kookpot met deksel
geschikt voor inductie
8597058 - Ø 20 cm
5523349 - Ø 24 cm
- 16** pan
geschikt voor inductie
3351380 - Ø 20 cm
7773029 - Ø 24 cm
8462934 - Ø 28 cm

Techno pro

vanaf
19,95
ST



Cosy
& Trendy
cook · dine · live




zoutmolen
1 6152MST - 25 cm
walnoot

pepermolen
2 6152T - 25 cm
walnoot

3 snijplank
2809385 - 46 x 33 x H 3 cm
2809386 - 60 x 40 x H 4 cm

4 koksmes
233600 - 20 cm



snijplank
7 7942900 - 30 x 20 x H 2,5 cm



tajine
geschikt voor inductie
8 3264506 - Ø 25 cm

kommetje
9 4515012 - Ø 12 x H 6 cm



brandertje
10 55598C

fondueset
11 1424243 - 9-dlg
6 vorkjes
1 brandertje

fonduenetjes
12 CT444101/2 - Ø 6,2 x 22,5 cm - set 3



broodplank bamboe
13 7631581 - 36 x 22,5 x H 2,5 cm
met metalen frame

botermesjes
14 2806229 - set 4



mengkom
15 1492 - Ø 17 x H 10 cm
16 3492 - Ø 26 x H 14 cm
17 6492 - Ø 22 x H 12 cm

Cosy
&Trendy
cook · dine · live





BIALETTI
CASA ITALIA

48,95

15,95

26,50

- 1 koffiekan
0001685 - voor 10 kopjes
geschikt voor inductie
- 2 koffiekan
0001163 - voor 6 kopjes
- 3 inductie-adaptor
DCDESIGN08 - Ø 13 cm



12,95

9

10

11

vanaf
1,65
ST

gasbrander
9 MTM806 - H 13,5 - 15 ml

Crème brûlée schaal
10 148/6 - Ø 14 cm - set 6
11 150/6 - Ø 11,5 cm - set 6
12 0152 - Ø 10 cm



24,95

Coty & Trendy
cook · dine · live

20

theepot
20 438501 - Ø 13 x H 18 cm - 0,8 L

pomphermos
21 183519 - 2,2 L

dubbelwandig kopje
22 2476418 - 22 cl - set 2
23 5413131 - 8 cl - set 2

Coty & Trendy
cook · dine · live

GENUINE
THERMOS
BRAND

12

- 4 deegrol
S21066 - Ø 5,8 x 45 cm
- 5 timer en uurwerk
17,5 x 10 x H 21 cm
8281654 ■ - 9616123 ■ - 5903486 ■
- bakvorm
6 5945878 - Ø 20 cm
7 79717A - Ø 25,5 cm
8 9130586 - Ø 22 x H 11,6 cm



3,95

9,95

14

13

- bakparels
13 8644091 - 300 gr
- 14 keukenweegschaal
min. 1gr - max. 5 kg
9153832 ■



38,95
SET

18

Coty & Trendy
cook · dine · live

theeset
18 131201SET - 1,2L - 4-dlg/pcs



21

59,95

6,50
SET

22

23

4,95
SET



Coty & Trendy
cook · dine · live

6,50

24,95

2,95

6,50

4

4,50

8

6

7



15

19,95

7,50
SET

16

6,50

17

- dubbelwandige fles
15 6740611 - Ø 5,3 x H 25,5 cm - 0,5 L
- dubbelwandige beker
16 7532887 - 30 cl - set 2
- chocolade plankje
17 7339661 - 29 x 15 cm - inc hamer



54,95
ST

19

alfi
FRESH · HOT · COLD

Gusto
schenkkkan mat
19 1 L - 3562205100 - 3561293100 - 3561290100
3561291100 - 3561294100



Amefa
since 1951

17,95
SET

24

25

Vintage

gebakvorkje
24 8840796 - set 6

koffielepel
25 5029281 - set 6

Gedrukt op 100%
gerecycled papier

Prijs- en modelwijzigingen, zet- en drukfouten voorbehouden. Leverbaar zolang de voorraad strekt.